


**1937M-01÷11**
**Accessories for item 1937M**

		art.		L mm	1937M-
	<b>019370101</b>	1937M-01	1937 M-01-rubber wheel eraser ø105x30.5	30	
	<b>019370102</b>	1937M-02	1937 M-02-rubber wheel eraser ø101x30.5	30	
	<b>019370103</b>	1937M-03	1937 M-03-fine-grain rotary brush 11 mm	11	
	<b>019370104</b>	1937M-04	1937 M-04-fine-grain rotary brush 23 mm	23	
	<b>019370105</b>	1937M-05	1937 M-05-coarse-grain rotary brush 11mm	11	
	<b>019370106</b>	1937M-06	1937 M-06-coarse-grain rotary brush 23mm	23	
*	<b>019370107</b>	1937M-07	1937 M-07-6 discs made of abras. fabric	16	
	<b>019370108</b>	1937M-08	1937 M-08-adaptor for single remov. disc	13	07
	<b>019370109</b>	1937M-09	1937 M-09-adaptor for double remov. disc	26	07
	<b>019370110</b>	1937M-10	1937 M-10-adaptor for wheels and brushes	11	03, 05
	<b>019370111</b>	1937M-11	1937 M-11-adaptor for rotary brushes	23	01, 02,

